



T-box

instrukcja obsługi / user manual / руководство пользователя / Gebruikershandleiding


TABLE OF CONTENTS

Installation	66
Navigation	66
Technical data	67
First run	68
Main screen	70
Main menu	70
Time	71
Date	71
Calendar	72
Language	75
Integrated units	76
Reset	76
Antifreeze	77
Leading sensor	77
Controller lock	78
External gas detector	78
Information menu	79
BMS	79
LEO fan heaters	80
LEO COOL fan cooler/heater	84
LEO EL fan heaters	88
KM mixing chambers	92
LEO D destratifiers	98
ROBUR gas heaters	100
ROBUR mixing chambers	102
ELiS air curtains	106
ELiS DUO air curtain-fan heater combo units	108
Slim air curtains	112
OXeN heat recovery units	116
OXeN EL heat recovery units	120
Cube Rooftop units	123
Alarms	128

INSTALLATION

T-box controller has a built-in sensor for measuring air temperature in the room. To ensure proper measurements, the controller should be installed at a height of approx. 1.5 m above the ground in a place with good air circulation. Do not place it near heat sources, lighting, air inlets, windows and door openings, etc.

If temperature sensor was chosen in a T-Box menu as „installed in unit“, T-box controller can be mounted out of area i.e. technical room.




NAVIGATION

-  return to previous screen with save of changes
-  return to previous screen without save of changes
-   menu navigation
-   change of parameter value
-   change of unit group

TECHNICAL DATA

Name	Description
Power supply	24 VDC
Way of control	touch screen
Temperature adjustment range	+5 ÷ +45°C
Operating temperature range	0 ÷ +60°C
Temperature sensor	built-in
Protection degree	IP20
Installation	on the wall
Casing	ABS plastic, RAL 9003
Max. number of connected units	31
Dimensions (HxWxD)	130 x 115 x 35 mm




* Applies to all devices connected to T-box Zone controller in line

** In case of Cube devices addressing is being done by service during first startup

In the case, when T-box in BMS network is the last device, SW1 switch should be set in T120 position.

DRV - SW1 ADDRESS SETTING



DRV - SW2 ADDRESS SETTING


Last DRV
in line



Others DRV
in line




FIRST RUN




Selection of language

 active language




Setting of date



Setting of time



 Searching of connected units.



LEO group of devices	08 device no 8 in LEO group
LEO water heater	KM water heater with mixing chamber
ROBUR gas heater	ROBUR KM gas heater with mixing chamber
LEO EL electric heater	DUO air curtain-fan heater combo unit
LEO D destratificator	ELIS air curtain
OXeN ventilation unit	LEO COOL fan cooler / heater
Cube rooftop units	Slim air curtain



- + Setting of desired temperature.

Check that all devices have been found. If not, check:

- correctness of connection of the A-A, B-B communication signal,
- power connection of the device,
- if address have been set correctly; each device must have a different address set, (in Cube devices the address is set by the service during the first start-up)
- if the SW2 dipswitch on the last device in line is set to T120 position. (in Cube devices, the dipswitch is set by the service during the first start-up)

MAIN SCREEN



 **long press** turn on/off of the controller

 **long press** main menu
short press units menu

 alarms

 setting of desired temperature

 set temperature

 measured temperature

 date, time

 settings lock active


 BMS mode active

 calendar active

 calendar active - settings forced

 the icon informs about changed position of OXeN dampers, or about Cube device start-up, the fans are suspended during this time.

long press Main menu



Enter to the menu after entering the password: 2014

 time setting

 date setting

 calendar

 language selection

 integrated units

 restore factory settings

 antifreeze


 selection of leading sensor

 controller lock


 external gas detector settings

 hardware version

 BMS settings



Setting of time



Setting of date

- For each day you can set up to 20 on/off events,
- Start time of new event is also the end time of previous event,
- For each event you can set any temperature for units, in the range of 5 – 45°C, For each event you can set for KM an air flow and dampers
- opening degree, for OXeN an air flow,
- Events for each day can be set individually or they can be copied from day, which was already set.

Activation of calendar is signaled on main screen via following icons:



calendar active – SYSTEM ON



calendar active – SYSTEM OFF




calendar active – settings forced.

There were ad hoc set other parameters than the settings programmed in the calendar:

- desired temperature,
- air flow for OXeN,
- the capacity or degree of opening of the KM and Cube dampers
- system were OFF and was turned on (to turn on the system press and hold for 2 s the calendar icon on main screen),
- system were ON and was turned off (to turn off the system press and hold for 2 s the calendar icon on main screen).

Ad hoc settings stays as long as time of current event in calendar. With start of next event, units will operate according to programmed settings.

Calendar



 activation/deactivation of calendar

 adding the event

 copying events on the following days


 removing the events

 moving to the next day

 event – system ON

 event – system OFF


Calendar – Adding the ON event



In given example SYSTEM will be turned on at 6:15 and the units will maintain temp. 12°C.

SYSTEM WILL OPERATE USING CURRENT SETTINGS UNTIL NEW EVENT WILL BE SET.

KM – additional settings for KM group
OXeN – additional settings for OXeN group
Cube – additional setting of Cube group.




For KM it is possible to set an air flow and dampers opening degree in current event.




Cont.

When the dampers are closed (no ventilation), it is possible to select the operating mode of the fan after reaching desired temperature. Fan can operate continuously or be turned off.



For OXeN it is possible to set an air flow in current event.



It is possible to set airflow and damper's degree of opening for a given zone.



Therm


When the therm mode is activated, the fans of the Cube will work in thermostatic mode - they will turn off after reaching the preset temperature in the room.



Auto


When Auto mode is activated, the Cube's throttle will be adjusted automatically until the set temperature is economically reached.

Calendar – Adding the OFF event



In given example units will be turned off at 16:00.
SYSTEM WILL BE TURNED OFF UNTIL THE NEXT EVENT,
ACCORDING TO CALENDAR SETTINGS.

Calendar – Copying events




Mon day from which events will be copied

Tue day selected for copying events from PN day

Thu day with already programmed operation schedule – you can also copy here the events from PN day

Fr day without programmed operation schedule


Calendar – Removing events



4:15PM **7:00PM** events selected to remove


 confirmation of events removal

Language



 active language

Integrated units



 searching for units integrated with system

 active unit

 deactivated unit
– not operating


System information



LEO M 01
CURTAIN MAIN
DRV-V 2.1
2.0.0-2d-....


 long press displays the DRV software

Reset



Restore default settings.

Antifreeze




Automatic protection against too low temperature in the room. When temperature in the room drops below desired temperature, LEO and KM units are turned on:

- valves (if installed) opens,
- fan is turned on at 100% of efficiency,
- KM dampers are closed, unit operates using recirculating air.

Units operate until the temperature in the room is higher of 1°C than antifreeze temperature, protecting the hall against too low temperature inside and freeze of heating medium in the exchanger.

Leading sensor




 active temperature sensor

 0.0°C leading sensor is the sensor built in T-box controller

 0.0°C leading sensor is the local sensor. When it is selected, operation of each unit is regulated locally

The correction of sensor measurements is also possible.

Controller lock




To activate the lock:

1. Set password
2. Confirm OK

Free 4-digit password can be set.

After returning to main screen and 30 s of inactivity, controller will be locked automatically.

External gas detector




The SYSTEM enables cooperation with an external CO₂ sensor, humidity sensor, etc. - two-stage alarm signal. The OXeN, KM and Cube capacity setpoint and the KM and Cube damper opening will be changed automatically depending on the alarm signal.

The central unit must be connected to one DRV OXeN, DRV KM control module or a controller in the Cube device.

In the menu, indicate to which device the central unit is connected.


In the example given, the control unit has been connected to DRV KM No. 7.

System information



Basic information about software and hardware version.

BMS – settings




ID – setting unit adress: from 1 to 247

BAUD – setting data transmission speed: from 9600 to 230400 bit/s

Physical layer: Modbus RTU

Protocol: RS485




 2 air flow setting – 3-steps

 selection of operating mode

 destratification

 readings



 active operating mode

 heating – heating medium valve is opened when measured temperature is lower than desired temperature


 cooling – heating medium valve is opened when measured temperature is higher than desired temperature

 ventilation – valve is constantly closed, fan operates continuously at selected speed

 Auto – automatic fan regulation depending on desired and measured temperature


 Manual – fan operates with constant, selected speed

Air flow setting




 air flow setting during operation in manual mode

 In MANUAL mode after reaching desired temperature fan can operate continuously on selected step: 1, 2, 3 or be turned off - select OFF.





Automatic air flow regulation according to desired and measured temperature, manual air flow regulation is not possible - inactive menu.



 In AUTO mode after reaching desired temperature fan can operate continuously on selected step: 1, 2, 3 or be turned off - select OFF.

Destratification



 heater activated for operation in destratification mode

LEO heaters can optionally operate in destratification mode (only heaters installed under the ceiling). When the measured temperature drops to the set temperature only fan starts. When the heat under the ceiling is not enough, and the temperature continues to decline (-1°C from the setpoint) valve will open.


The heater must be equipped with T3 sensor (optional equipment).

 activation of destratification mode

 setting of temperature difference (difference between temperature under the ceiling and temperature in the occupied zone), at which LEO heaters will be turned on

 selection of heaters, which should operate in destratification mode

Readings



 Temperature under the ceiling


 Temperature in the room

 ON/OFF valve

To read temperatures near the unit, external temperature sensors PT-1000 must be connected to DRV control module.

LEO COOL


-type fan cooler / heater



 2 air flow setting – 3-steps

 selection of operating mode

 readings



 active operating mode

 heating – heating medium valve is opened when measured temperature is lower than desired temperature


 cooling – heating medium valve is opened when measured temperature is higher than desired temperature

 ventilation – valve is constantly closed, fan operates continuously at selected speed

 Auto – automatic fan regulation depending on desired and measured temperature


 Manual – fan operates with constant, selected speed

Air flow setting




 air flow setting during operation in manual mode

 In MANUAL mode after reaching desired temperature fan can operate continuously on selected step: 1, 2, 3 or be turned off - select OFF.




Automatic air flow regulation according to desired and measured temperature, manual air flow regulation is not possible - inactive menu.



 In AUTO mode after reaching desired temperature fan can operate continuously on selected step: 1, 2, 3 or be turned off - select OFF.

Readings




 Temperature in the room

 ON/OFF valve

To read temperatures near the unit, external temperature sensors PT-1000 must be connected to DRV control module.




-  2 air flow setting – 3-steps
-  2 heating power setting
-  selection of operating mode
-  destratification
-  readings



-  active operating mode
-  heating
 -  automatic fan and heaters power regulation depending on desired and measured temperature
 -  manual regulation of airflow and heaters power
-  ventilation – heaters are OFF, fan operates at selected speed continuously


Airflow



 air flow setting during operation in manual mode

 In MANUAL mode after reaching desired temperature fan can operate continuously on selected step: 1, 2, 3 or be turned off - select OFF.



Heating power



 heating power setting - 3 steps

 heating power setting - 2 steps

Destratification



 02 heater activated for operation in destratification mode

LEO heaters can optionally operate in destratification mode (only heaters installed under the ceiling). When the measured temperature drops to the set temperature only fan starts. When the heat under the ceiling is not enough, and the temperature continues to decline (-1°C from the setpoint) heaters are ON.


The heater must be equipped with T3 sensor (optional equipment).

 activation of destratification mode

 setting of temperature difference (difference between temperature under the ceiling and temperature in the occupied zone), at which LEO heaters will be turned on

 selection of heaters, which should operate in destratification mode

Readings




 Temperature under the ceiling


 Temperature in the room

 Chosen heat power

To read temperatures near the unit, external temperature sensors PT-1000 must be connected to DRV control module.




-  100% air flow setting – depending on LEO model stepless or 3-steps
-  operating modes
-  100% dampers setting - stepless
-  readings
-  filters operating status
-  selection of leading sensor
-  roof fan setting
-  dampers setting according to external temperature



-  active operating mode
-  **heating** – valve is opened when measured temperature is lower than desired temperature
-  **cooling** – valve is opened when measured temperature is higher than desired temperature
-  **ventilation** – valve is constantly closed, fan operates continuously at selected step

Air flow setting




air flow setting – 3-steps

 Appearance of this icon informs that the air flow setting has been defined in the calendar. It is possible to change it ad hoc only. Change will only be active in given calendar zone.

 When the dampers are closed (no ventilation), it is possible to select the operating mode of the fan after reaching desired temperature. Fan can operate continuously or be turned off.

Air flow setting – gas detector




Operation with gas detector should be activated – see point „External gas detector” on page 66.

Three values of air flow should be defined:

- normal operation status
- 1 – first step of alarm from gas detector
- 2 – second step of alarm from gas detector


Dampers setting



Appearance of this icon informs that the air flow setting has been defined in the calendar. It is possible to change it ad hoc only. Change will only be active in given calendar event.

When the dampers are closed (no ventilation), it is possible to select the operating mode of the fan after reaching desired temperature. Fan can operate continuously or be turned off.

Dampers setting – gas detector




Operation with gas detector should be activated – see point „External gas detector“ on page 66.

Three values of air flow should be defined:

- normal operation status
- 1 – first step of alarm from gas detector
- 2 – second step of alarm from gas detector

Readings



External temperature




Temperature in the room



Temperature of air supplied into the room



Temperature of heating medium on return pipe



Desired temperature of supply air



ON – automatic setting of dampers according to external temperature is active – see p. 37




dampers opening degree




ON/OFF valve

Filters operating time counter




After reaching the limit of working hours, there will be displayed an indication in alarm menu. Value must be reset. Alarm does not affect the operation of the unit.

Filters operating time limit



Value should be set according to building contamination level.

Temperature sensor




■ active temperature sensor

□⁺ Leading sensor is the ambient air temperature sensor (built in T-box or local, near the unit). When temperature in the room is not reached, SRX3d valve is open in 100%. When temperature in the room is reached, flow of heating medium is regulated in such way, that the supply air temperature is equal to set temperature.

□⁺ Leading sensor is the supply air temperature sensor. Controller will maintain supply air temperature set on the main screen, thanks to regulation of the flow of heating medium by SRX3d valve opening degree.

— + correction of air temperature set on main screen

Roof fan setting



 active setting

 roof fan change air volume according to present dampers opening level and air flow of LEO heater


 roof fan change air volume according to present dampers opening level

Setting „0%“ means balance between air removed by roof fan and supplied by KM heater.

Positive value means that the roof fan removes more air than the KM supplies (under-pressure). Setting „+100%“ means continuous operation of the roof fan.


Negative value means that the roof fan removes less air than the KM supplies (overpressure). Setting „-100%“ means operation of the KM only.

Dampers setting according to external temperature



Automatic setting of dampers opening level according to external air temperature.

Value set here is overriding normal damper setting and setting in calendar.




 2 air flow setting – 3-steps

 selection of operating mode

 readings

 settings of manual operating mode

 settings of auto operating mode



 active operating mode

 **Auto** – integration of operation of destratifiers with LEO heaters and effective use of heat from upper zones of the room. Destratifiers are turned on automatically, when there is suitable amount of heat accumulated in the upper zones of the room. Units press of warm air down to occupied zone. When amount of heat is insufficient, LEO heaters are turned on automatically.

 **Manual** – destratificator operates in ON/OFF mode. It is turned on when temperature under the ceiling is higher than set temperature.

Readings




 Temperature under the ceiling

 Temperature in the room


To read temperatures near the unit, external temperature sensors PT-1000 must be connected to DRV control module.

Settings of auto operating mode




Setting of temperature difference (difference between temperature under the ceiling and temperature in the occupied zone), at which LEO D units will be turned on.


Settings of manual operating mode



Destratificator operates in ON/OFF mode. It is turned on when temperature under the ceiling is higher than set temperature.




-  burner power settings
-  operating modes
-  readings
-  thermal protection settings



-  active operating mode
-  heating mode – burner and fan is working according to temperature
-  heating-auto – automatic selection of the burner power depending on the measured temperature
-  heating-manual – manual selection of the burner power
-  ventilation mode - fan is working continuously, burner is OFF
-  unit is OFF


Airflow




 burner power setting in heating-manual mode

 in heating operation mode after reaching the set temp. the fan may work continuously - ON or be turned off - OFF

Readings




Thermal protection




 max. operating temperature
OFF

 temperature ready for restart
ON

ROBUR KM mixing chambers




- dampers setting - stepless
- burner power settings
- operating modes
- dampers setting according to external temperature
- readings
- thermal protection settings
- filters operating status
- roof fan setting




- active operating mode
- heating mode – burner and fan is working according to temperature
- heating-auto – automatic selection of the burner power depending on the measured temperature
- heating-manual – manual selection of the burner power
- ventilation mode – fan is working continuously, burner is OFF
- unit is OFF

Air flow




- burner power setting in heating-manual mode
- in heating operation mode after reaching the set temp. the fan may work continuously - ON or be turned off - OFF

Readings



Dampers setting




- Appearance of this icon informs that the air flow setting has been defined in the calendar. It is possible to change it ad hoc only. Change will only be active in given calendar zone.

70% damper setting in heating mode

30% damper setting in heating-continues mode

- outlet air temp., STB protection.
- external temperature
- temperature in the room
- dampers opening degree
- ON – automatic setting of dampers according to external temperature is active.


Thermal protection



 max. operating temperature
OFF


 temperature ready for restart
ON

Filters operating time counter




After reaching the limit of working hours, there will be displayed an indication in alarm menu. Value must be reset. Alarm does not affect the operation of the unit.

Filters operating time limit



Value should be set according to building contamination level.

Roof fan setting




Setting „0%“ means balance between air removed by roof fan and supplied by ROBUR KM heater.



Positive value means that the roof fan removes more air than the ROBUR KM supplies (under-pressure). Setting „+100%“ means continuous operation of the roof fan.

Negative value means that the roof fan removes less air than the ROBUR KM supplies (overpressure). Setting „-100%“ means operation of the ROBUR KM only.

Dampers setting according to external temperature



Automatic setting of dampers opening level according to external air temperature. Value set here is overriding normal damper setting and setting in calendar.



 2 air flow setting – 3-steps

 selection of operating mode

 setting of delay times

 readings

 antifreeze

 active operating mode


 K1 air curtain operates according to door sensor and thermostat, whose priority is equivalent

 K2 air curtain operates according to door sensor and thermostat. Door sensor has a priority. Without it's signal unit will not run

 heating – valve is opened when measured temperature is lower than desired temperature

 ventilation – valve is constantly closed, fan operates continuously at selected step


Air flow setting



 air flow setting

 **Cont.** After the disappearance of signal from the door sensor (or thermostat if K1 mode is activated), fan of air curtain can operate on selected step for a specified period of time or be turned off - select OFF.

Setting of delay time




 Fan switch off delay time – it can be set in the range 0:00 - 10:00 minutes, every 0:30 s. It is possible to set ∞ value, then fan operates continuously.

 Valve switch off delay time - it can be set in the range 0:00 - 10:00 minutes, every 0:30 s. It is possible to set ∞ value, then valve is constantly open.


Valve delay time must be shorter than fan delay time.

Antifreeze



Antifreeze protection of the heat exchanger. When temperature in the room drops below desired temperature fans stops and valve is open to 100%. The unit must be equipped with T3 sensor (optional equipment).

Readings



To read temperatures near the unit, external temperature sensors PT-1000 must be connected to DRV control module.

short press **ELiS DUO air curtain-fan heater combo units**



 2 air flow setting for air curtain part – 3-steps

 2 air flow setting for fan heater part – 3-steps

 selection of operating mode


 setting of delay times

 readings

 antifreeze

ON/OFF valve 
Temperature in the room 


Operating modes



-  active operating mode
-  K1 air curtain operates according to door sensor and thermostat, whose priority is equivalent
-  K2 air curtain operates according to door sensor and thermostat. Door sensor has a priority. Without it's signal unit will not run
-  **heating** – valve is opened when measured temperature is lower than desired temperature
-  **ventilation** – valve is constantly closed, fan operates continuously at selected step


Fan heater operates always according to temperature set on the controller, regardless K1/K2 mode.

Air flow setting



-  air flow setting


 **Cont.** After the disappearance of signal from the door sensor (or thermostat if K1 mode is activated), fan of air curtain can operate on selected step for a specified period of time or be turned off - select OFF.



 air flow setting

 After reaching desired temperature fan of the heater can operate continuously on selected step: 1, 2, 3 or be turned off - select OFF.


Setting of delay time



 fan switch off delay time can be set in the range 0:00 - 10:00 minutes, every 0:30 s. Value ∞ - fan operates continuously.

 valve switch off delay time can be set in the range 0:00 - 10:00 minutes, every 0:30 s. Value ∞ - valve is constantly open.

Antifreeze




Antifreeze protection of the heat exchanger. When temperature in the room drops below desired temperature fans stops and valve is open to 100%. The unit must be equipped with T3 sensor (optional equipment).

Readings



 Temperature in the room  ON/OFF valve

To read temperatures near the unit, external temperature sensors PT-1000 must be connected to DRV control module.




 2 air flow setting – 3-steps

 selection of operating mode

 setting of delay times

 readings

 antifreeze



 active operating mode


 K1 air curtain operates according to door sensor and thermostat, whose priority is equivalent

 K2 air curtain operates according to door sensor and thermostat. Door sensor has a priority. Without it's signal unit will not run

 heating – valve is opened when measured temperature is lower than desired temperature

 ventilation – valve is constantly closed, fan operates continuously at selected step


Air flow setting



 air flow setting

 **Cont.** After the disappearance of signal from the door sensor (or thermostat if K1 mode is activated), fan of air curtain can operate on selected step for a specified period of time or be turned off - select OFF.

Setting of delay time




 Fan switch off delay time – it can be set in the range 0:00 - 10:00 minutes, every 0:30 s. It is possible to set ∞ value, then fan operates continuously.

 Valve switch off delay time - it can be set in the range 0:00 - 10:00 minutes, every 0:30 s. It is possible to set ∞ value, then valve is constantly open.


Valve delay time must be shorter than fan delay time.

Antifreeze




Antifreeze protection of the heat exchanger. When temperature in the room drops below desired temperature fans stops and valve is open to 100%. The unit must be equipped with T3 sensor (optional equipment).

Readings



To read temperatures near the unit, external temperature sensors PT-1000 must be connected to DRV control module.

 Temperature in the room  ON/OFF valve



 100% air flow setting – stepless


 operating modes

 readings

 filters operating status

 selection of leading sensor

 this icon inform that dampers are during change of position, fan are stopped




 active operating mode

 **Operation with heat recovery** – operation in this mode ensures heat or cool recovery from removed air

 **Operation without heat recovery** – supply air is directed via by-pass without heat recovery („freecooling“/„free-heating“).


 Automatic change of operating mode with or without heat recovery, depending on temperature

Air flow setting



 Appearance of this icon informs that the air flow setting has been defined in the calendar. It is possible to change it ad hoc only. Change will only be active in given calendar event.

Air flow setting – gas detector




Operation with gas detector should be activated – see point „External gas detector” on page 66.

Three values of air flow should be defined:

- normal operation status
- 1 – first step of alarm from gas detector
- 2 – second step of alarm from gas detector

Readings



External temperature




Temperature in the room



Temperature of air supplied into the room



Temperature of heating medium on return pipe



Desired temperature of supply air



Temperature of removed air



ON – status of by-pass dampers




ON – status of external dampers




ON/OFF valve

Control of the filters pollution




Control of the filters pollution



Set the required alarm value, where 1 means an alarm a small filter pollution, 5 means an alarm a very pollution filter.

Temperature sensor




 active temperature sensor


 Leading sensor is the ambient air temperature sensor (built in T-box or local, near the unit). When temperature in the room is not reached, SRX3d valve is open in 100%. When temperature in the room is reached, flow of heating medium is regulated in such way, that the supply air temperature is equal to set temperature.

 Leading sensor is the supply air temperature sensor. Controller will maintain supply air temperature set on the main screen, thanks to regulation of the flow of heating medium by SRX3d valve opening degree.

 correction of air temperature set on main screen




-  100% airflow setting - only 100%
-  3 heating power setting
-  operating modes
-  readings
-  filters operating status
-  this icon inform that dampers are during change of position, fan are stopped
 this icon inform also that fans cooling the heater



-  Activ operating mode
-  **Operation with heat recovery** – operation in this mode ensures heat or cool recovery from removed air
-  **Operation without heat recovery** – supply air is directed via by-pass without heat recovery („freecooling“/„free-heating“).
-  automatic setting of heating power
-  manual setting of heating power

Readings




External temperature



Temperature in the room



Temperature of air supplied into the room



Temperature of removed air



ON – status of by-pass damper



ON – status of external dampers



chosed of heating power


POLSKI

ENGLISH

РУССКИЙ

NEDERLANDS

Heating power



-  3 Heating power setting:
- 3 – 8,5 kW
 - 2 – 5,5 kW
 - 1 – 3,5 kW


Control of the filters pollution



Control of the filters pollution




Set the required alarm value, where 1 means an alarm a small filter pollution, 5 means an alarm a very pollution filter.




-  ON capacity setting
-  100% damper setting
-  operation modes
-  readings

Damper 0% – recirculation damper closed.
 Damper 100% – the device operates only on recirculated air.



-  active operating mode
-  swirl diffuser setting for manual mode
-  swirl diffuser setting for heating in automatic mode
-  swirl diffuser setting for cooling in automatic mode
-  automatic mode - the swirl diffuser setting changes automatically between the setpoint for cooling or heating depending on the active operating mode of the Cube. For cooling, optimal airflow is horizontal and for heating it is vertical
-  manual mode - fixed swirl diffuser setting

Capacity setting



 active operating mode


 airflow setting

 The icon informs that the parameter has been defined in the calendar. It is possible to change the parameter temporarily. The change will only be active in a given calendar zone

 Thermostatic mode - Fans turn OFF after reaching the set temperature. The option is not available when the device is operating in according to the supply air temperature sensor as a leading sensor.

The selection of the leading/master sensor from: supply air, exhaust air and wall temperature sensors is made during first startup. It is also possible to define built in sensor in T-box sensor as the leading sensor

Capacity setting - gas detector




 active operating mode

Activate the functions of working with a gas detector - see section „External gas detector” on page 14.

You need to define 3 parameter values:

- normal working condition
- 1 - first level of alarm from gas detector
- 2 - second level of alarm from gas detector

Dampers setting



 active operating mode


 airflow setting

 The icon informs you that the parameter has been defined in the calendar. It is possible to change the parameter temporarily. The change will only be active in that calendar zone

 Manual setting of the recirculation damper position

 The position of the recirculation damper is changed automatically depending on air temperatures.

Damper setting - gas detector



 active operating mode



Activate the functions of working with a gas detector - see section „External gas detector” on page 78.

You need to define 3 parameter values:

- normal working condition

- 1 - first level of alarm from gas detector - 2 - second level of alarm from gas detector

Readings



outside temperature



temperature of the air supplied to the room



temperature of the air exhausted from the room



temperature at the return of the medium



room temperature

Room temperature reading from the T-box controller's built-in sensor or from the optional NTC wall-mounted sensor, connected to the Cube control box/enclosure



current setting of the recirculation damper



current swirl diffuser setting




air flow



the current state of the gas detector



current general operating mode:
 Vent - ventilation
 Heat - heating HeatRec - heat recovery
 Cool - cooling
 CoolRec - cool recovery



current operating mode:

Stop - device stopped

Freeze - frost alarm

Off - device turned off.

Startup - starting

ECO mode - economic mode (applies to Climatix regulation)

COMF mode - comfort mode

Forcing - active signal from an external detector (option)


Thermostat - the device works in thermostatic mode

NightCool - the device works in the night cooling mode (applies to Climatix regulation)

Overrun - cooling down process

Defrosting - defrosting the heat pump (optional)

ALARMS




warnings

- **Gas sensor: level 1**
signal from gas detector, level I
- **Gas sensor: level 2**
signal from gas detector, level II
- **Antifreeze heat recover exchanger ON**
antifreeze mode of heat recovery exchanger is on
- **Filter work time**
check filters contamination level
- **Filter pressure**
dirty filter of KM, change the filter, if pressure switch is not applied make a bridge (jumper) between PRDN IN and GND
- **Forcing damper ON**
forcing damper settings depending on the outside temperature
- **Rooftop maintenance alarm**
Maintenance works necessary

alarms

- **Real time clock error**
reset the T-box clock
- **Temperature sensor T1/T2/T3/T4/T5**
check the temperature sensor
- **Roof fan fuse**
check the fuse of the roof fan on the DRV board
- **Roof fan TK**
roof fan thermal protection alarm
- **Fan 3V fuse**
check the LEO heater fan fuse on the DRV
- **Fan EC fuse**
check EC fan fuse on DRV board
- **Fan EC not connected**
check the connection of the EC fan
- **Antifreeze water exchanger ON**
water exchanger antifreeze mode is activated

List of alarms



- **DRV group error**
Addressing failure. Check binary address set in DRV and use search button again
- **Connection error**
no communication between DRV and T-box, check connection and DRV power supply
- **DUO heater not connected**
no communication between DRV of fan heater part of ELiS DUO, check connection between DRV of air curtain part and DRV of fan heater part
- **Rooftop warning alarm**
alarm with device operation support
- **Rooftop fault alarm**
alarm that prevents further operation of the device
- **Rooftop danger alarm**
alarm that immediately disconnects all device functions

Declaration Of Conformity UE

FLOWAIR hereby declare that the T-box controller were produced in accordance to the following Europeans Directives:

2014/30/UE – Electromagnetic Compatibility (EMC)

2014/35/UE – Low Voltage Electrical Equipment (LVD)

and harmonized norms ,with above directives:

PN-EN IEC 61000-3-2:2019-04 – Electromagnetic compatibility (EMC) — Part 3-2: Limits — Limits for harmonic current emissions (equipment input current ≤ 16 A per phase)

PN-EN 61000-3-3:2013-10 – Electromagnetic compatibility (EMC) — Part 3-3: Limits — Limitation of voltage changes, voltage fluctuations and flicker in public low-voltage supply systems, for equipment with rated current ≤ 16 A per phase and not subject to conditional connection

PN-EN IEC 61000-6-2:2019-04 – Electromagnetic compatibility (EMC). Generic standards. Immunity for industrial environments

PN-EN 61000-6-3:2008/A1:2012 – Electromagnetic compatibility (EMC) — Part 6-3: Generic standards — Emission standard for residential, commercial and light-industrial environments

PN-EN 60065:2015-08 – Audio, video and similar electronic apparatus — Safety requirements

PN-EN 55022:2010 – Information technology equipment — Radio disturbance characteristics — Limits and methods of measurement

PN-EN 60068-2-1:2009 – Environmental testing

PN-EN 60068-2- 2:2009 – Environmental testing

Gdynia, 01.04.2020
Product Manager
Wojciech Bednarczyk

